Protect your pressure washer from freezing! How to winterize your equipment

Hot water (coil type) Machines:

- 1. Remove nozzle from end of wand.
- 2. Turn off and disconnect water supply. Turn on pump to empty float tank.
- 3. Drain any remaining water from float tank by removing drain plug on bottom of float tank.
- 4. Locate air valve on water pump and connect an air hose to blow water out of pump, coil, and hose. If machine has a trigger gun, hold gun open during this step. Turn pump an few revolutions by hand to get any remaining water out and reconnect air hose for about 30 seconds or until all water is out of the system.
- 5. Replace pressure nozzle.
- 6. Store machine in warm, dry building.

OR---

- 1. Fill float tank with anti-freeze.
- 2. Turn machine on and run unit until you see the color of the anti-freeze coming out of the nozzle.
- 3. Let run about 10 seconds.

It will probably take several gallons of anti-freeze to complete the process.

YOU WILL HAVE TO FREEZE PROTECT YOUR MACHINE EACH TIME YOU USE IT IN THE WINTER!!

Cold water machines

- 1. Turn off water supply and disconnect hoses, water supply and high pressure.
- 2. Turn machine on for 15 seconds or until all water is out of system.
- 3. Drain high pressure hose. (Hold trigger gun vertically in the air, squeeze and let all the water drain out of the hose and trigger.
- 4. Store in dry building.

OR---

- 1. Run chemical line into a gallon of anti-freeze (RV).
- 2. Turn machine on and insert black nozzle into quick coupler to activate chemical pick up.
- 3. Run until you see the color of the anti-freeze coming out of the nozzle.
- 4. Let run about 15 seconds.

YOU WILL HAVE TO FREEZE PROTECT YOUR MACHINE EACH TIME YOU USE IT IN THE WINTER!!

Note: If you need more information, just give us a call. We will be glad to tell you how to protect you equipment from the cold.

We can be of better assistance if you know the brand and model of your equipment.

4319 CRITTENDEN DRIVE LOUISVILLE, KY 40209 PHONE: (502) 367-2239



1009 EASTLAND DR. LEXINGTON, KY 40505 PHONE: (859) 255-6515